


MITURO



Technical specifications

Bulb: LED
Luminous Flux: 178 Lumen
Output: 5 W
Protection Class: III
IP Code: IP54
Light Colour: 3000 K
Ra/CRI 80
Voltage: DC 3,7 V
Input: 5V/DC 2A
Dimensions: H 45 cm x 17 cm
Burning Period: 5-30 h



Read the operating instructions carefully before using the lamp for the first time. Please keep these instructions for future reference. If you pass the lamp on to third parties, be sure to include these instructions.

GENERAL

These safety and usage instructions are part of the mobile led-lamp setup (hereinafter referred to as the 'lamp'). It contains important information about commissioning and handling.

Read the operating instructions carefully before using the lamp, especially the safety instructions. Failure to follow these instructions may result in serious injury or damage to the lamp.

The safety and usage instructions are based on the standards and rules that are valid in the European Union. In addition, follow country-specific guidelines and laws abroad.

This lamp contains built-in LED bulbs.

The LED bulbs cannot be changed in the lamp. If the LED bulbs are defective, the entire lamp must be replaced.

This product contains a light source of energy efficiency class G. Lifetime of LED: > 20.000 h

Hazards for children and persons with reduced physical, sensory or mental abilities (e.g. partially disabled, elderly persons with limited physical and mental abilities) or persons with a lack of experience and knowledge (e.g. older children).

- This lamp can be used by children aged eight and over, and by persons with reduced physical, sensory or mental abilities or a lack of experience and knowledge, if they have been supervised or instructed in the safe use of the lamp and understand the resulting hazards. Children are not allowed to play with the lamp. Cleaning and maintenance must not be performed by children without supervision.
- Keep children younger than eight years away from the lamp and the connection cable.
- Do not leave the lamp unattended when operating it.
- Do not let children play with the packaging film. Children can get caught up in it and suffocate when playing.

RISK OF AN EXPLOSION AND FIRE!

- Improper handling of the lamp can cause an explosion or fire.
- Keep the lamp away from water, other liquids, open fire and hot surfaces.
- Do not cover the lamp or the mains plug with objects or clothing..
- Keep a distance of at least 10 cm from easily flammable materials.
- Do not expose the lamp to excessive heat, such as direct sunlight, fire etc.

RISK OF INJURY!

- The light of the LED is very bright and can damage the eyes if it is looked at directly.
- Never look directly into the illuminated LED of the lamp.
- When using the lamp, take care not to shine it into the eyes of people or other living creatures.

RISK OF DAMAGE!

- Improper handling of the lamp can result in damage to the lamp.
- Install the lamp on an easily accessible, level, dry, heat-resistant and sufficiently stable surface.
- Do not place the lamp on the edge of the surface.
- Do not place the lamp on or near hot surfaces (cookers etc.).
- Do not bring the lamp or mains cable into contact with hot parts.
- Do not expose the lamp to weather conditions (rain etc.).
- Do not use the lamp if it is damaged, e.g. cracks, fissures or deformation. If this happens, dispose of the lamp properly.
- The light source of this lamp cannot be replaced. When the light source reaches the end of its life, replace the entire lamp.

USING THE LAMP FOR THE FIRST TIME

Check the lamp and the scope of delivery

Risk of damage! If you open the packaging carelessly with a sharp knife or other pointed object, the lamp can be quickly damaged.

- When opening, proceed with caution
- 1. Remove the lamp from the packaging.
- 2. Check that the scope of delivery is complete.
- 3. Check whether the lamp is damaged. If this is the case, do not use the lamp and contact the manufacturer.

Charging the lamp

Before using for the first time, charge the lamp fully. It is not possible to use the lamp during the charging process.

- For charging, place the lamp on a dry, horizontal surface.
- Fully unwind the USB charging cable.
- Insert the USB plug into the charging socket.
- Insert the USB plug into a USB power source (e.g. computer, USB charger). Whilst the light is being charged, the charging indicator light turns red.
- When the lamp is fully charged, the charging indicator light turns green. You can use the lamp.

OPERATION

The lamp offers three brightness levels (20 %, 50 % and 100 %). It is also infinitely dimmable in between these levels.

- To switch on the lamp, touch the control ele-

EXPLANATION OF SYMBOLS

Declaration of Conformity - Products marked with this symbol comply with all applicable Community legislation of the European Economic Area.

This symbol indicates that the lamp complies with protection class III.

This symbol shows the IP code of the lamp. The lamp is splash-proof.

This symbol indicates a hazard with a medium level of risk which, if not avoided, can result in death or serious injury.

This symbol indicates a hazard with a low level of risk which, if not avoided, may result in minor or moderate injury.

Certification mark that indicates conformity with the applicable requirements for products sold within Great Britain.

SAFETY

Intended use

The lamp is exclusively designed for use indoors and outdoors in temperatures ranging between 0 °C and 40 °C. It is exclusively for private use and not for commercial applications.

Only use the lamp as described in these operating instructions: Any other form of use is considered improper use and may result in damage to property or even personal injury. The lamp is not a children's toy.

The manufacturer or dealer accepts no liability for damage caused by improper or incorrect use

RISK OF AN ELECTRIC SHOCK!

Incorrect electrical installation, excessively high mains voltage as well as damage and improper handling of the lamp may lead to electric shock.

- Only connect the lamp if the mains voltage of the socket corresponds to the information on the rating plate.

- Do not operate the lamp if there is visible damage or if the power cord or plug is defective.

- Do not open the housing. Instead leave the repair for qualified staff to carry out. Contact a specialist workshop for this purpose. Liability and warranty claims are excluded in the event of repairs or modifications performed by yourself, improper connection or incorrect operation.

- Only parts that correspond to the original device data may be used for repairs. This lamp contains electrical and mechanical parts which are essential for protection against hazards.

- Do not operate the lamp with a external time switch or a separate remote control system.

- Do not immerse the lamp, power cord or plug in water or other liquids.

- Never touch the mains plug with wet hands.

- Never pull the mains plug out of the socket by the power cord. Always touch the mains plug.

- Never use the mains cable as a carrying handle. - Keep the lamp and power cord away from naked flames and hot surfaces.

- Lay the power cord so that it does not become a trip hazard.

- Do not bend the mains cable or place it over sharp edges.

- Never use the lamp in damp rooms or in the rain.

- Never store the lamp so that it can fall into a bathtub or sink.

- Never reach for an electrical appliance if it has fallen into water.

- Make sure that children do not insert objects into the lamp.

- If you do not use the lamp, if you clean it or if a fault occurs, always switch the lamp off and unplug it from the mains.

ment on the top of the lamp head. The LEDs light up with the brightness level 20 %.

- In order to increase the brightness continuously, keep this button pressed until the (desired) light intensity is reached.

- In order to gradually increase the brightness, touch the button several times. The LEDs light up in the three brightness levels.

- The lamp can be dimmed from 100%

- In order to switch the lamp off, touch the button again.

Please refer to the additional information in the illustrated operating instructions which are supplied.

CLEANING

Risk of a short circuit!

Water or other liquids that have entered the housing may cause a short circuit.

- Never immerse the lamp in water or other liquids.

- Make sure that no water or other liquids get into the housing.

RISK OF DAMAGE!

Improper handling of the lamp can result in damage to it.

- Do not use cleaning agents containing solvent, abrasive cleaning agents, brushes with metal/nylon bristles or sharp-edged/metallic cleaning objects such as knives, hard scrapers etc.

These can damage the surfaces.

- Never put the lamp in the dishwasher. It would destroy the lamp.

1. Allow the lamp to cool down completely.
2. Use a soft cloth moistened with lukewarm water and soap in order to clean the lamp.
3. Allow all parts to dry completely.

STORAGE

- Always store the lamp in a dry place.

- Protect the lamp from direct sunlight.

- Store the lamp out of the reach of children.

Store it securely closed at a storage temperature between 5 °C and 20 °C (room temperature).

DISPOSAL

Disposal of the packaging

Dispose of the packaging according to type. Put card and cardboard in with the waste paper. Put film into the recyclable waste collection.

Disposal of the lamp

(Applicable in the European Union and other European countries with systems for the separate collection of recyclables)

Old appliances should not be disposed of with household waste!

If the lamp can no longer be used, the consumer is legally obliged to dispose of old appliances separately from household waste, e.g. at a collection point organised by the local council. This ensures that waste products are properly recycled and that negative environmental effects are avoided. Therefore, electrical appliances are marked with the symbol that is shown here.

Batteries should not be disposed of with household waste!

As a consumer, you are legally obliged to dispose of all batteries, whether or not they contain harmful substances, at a collection point in your neighbourhood or hand them over to a trader so that they can be disposed of in an environmentally-friendly manner. Please dispose of the lamp in full (with the battery) at your local collection point. Please ensure that the battery has been discharged!

CONTACT INFORMATION

blomus GmbH
Zur Hubertushalle 4 | 59846 Sundern | Germany
www.blomus.com

E-mail: kundenservice@blomus.com
Telephone: +49 (0)2933 831-130